

Soma

by Laurie Wiid van Heerden






Soma is the Greek word for “body” and Laurie Wiid van Heerden’s design of the Soma is inspired by the body of a tree. The trunk like shape carries leaves towards the sky raising them upwards and above other plants. The Soma planters, some which are substantial in size, do the same and lift beautiful plants up via a curvaceous tree trunk likeness which could include timber as part of that body of the tree.





SPECIFICATIONS




SOM13W

stone with wood

weight: W 110kg

inch: 31.2x27.6x51.2"




SOM13S

all stone

weight: 120kg (302lb)

inch: 31.2x27.6x51.2"




SOM12W

stone with wood

weight: W 65kg

inch: 22x19x47.2"




SOM12S

all stone

weight: 85kg (187lb)

inch: 22x19x47.2"




SOM10W

stone with wood

weight: W 75kg

inch: 28.9x27.6x39.4"




SOM10S

all stone

weight: 85kg (247lb)

inch: 28.9x27.6x39.4"




SOM07W

stone with wood

weight: W 55kg

inch: 27.6 x 27.6 x 27.6"




SOM07S

all stone

weight: 55kg (205lb)

inch: 27.6 x 27.6 x 27.6"




SOM09S

all stone

Weight 38kg/86lb

inch: 16.3x14x35"




SOM09W

stone with wood

Weight W 42kg

inch: 16.3x14x35"


LINERS



round

soil: 16 gal | 61 l


volume: 0.8 gal | 3.4 l



round

soil: 3.6 gal | 14 l

water: 0.8 gal | 3 l





round

soil: 4.27 gal | 16.17

water: 0.92 gal | 3.51 l

Finish Options



natural wood



oiled wood

Liners




“Self-Watering” Liners

All Indigenus planters come with a liner for planting. The drawings show the sizes and capacities. These liners have been designed to house plants in proportion to the size of the planters. They contain a water reservoir at the base into which the roots grow. Using the process of “capillary action” the water is pushed up into the soil.

Water levels in the reservoir can be measured using the cap gauge and the liner has a plug which must be removed if the planter is exposed rainfall.

The liners usually need 14 weeks to integrate with the root system during which watering should be done the normal way onto the soil. Thereafter in typical conditions the reservoir only needs filling once or twice a month



Always use the planter in conjunction with the liner and remove the plug at the base of the liner and the base of the planter if the planters are going to receive rainfall.

